

Lecture 6: Rheology – Measuring "Softness" and Time-Dependent Response

Key Topics

What is Rheology?

Definition: The study of flow and deformation of matter

Central Question: How do we quantify the softness or flow behavior of a material?

Focus:

- Experimental rheology
- Storage and loss moduli (G' , G'')
- Viscosity as function of shear rate or frequency
- Relaxation timescales

Storage and Loss Moduli

Linear Viscoelastic Characterization

Method: Small oscillatory deformations

Apply oscillating strain:

$$\gamma(t) = \gamma_0 \sin(\omega t)$$

Measure resulting stress:

$$\sigma(t) = \gamma_0 [G' \sin(\omega t) + G'' \cos(\omega t)]$$

Storage Modulus (G')

Physical Meaning:

- **In-phase** stress response
- Energy **stored** like a spring
- Measure of material **stiffness**
- Elastic component

When G' dominates:

- Material behaves solid-like
- Most energy stored and recovered
- Little energy dissipation

Loss Modulus (G'')

Physical Meaning:

- **Out-of-phase** stress response
- Energy **dissipated** as heat like a dashpot
- Viscous component
- Energy lost per cycle

When G'' dominates:

- Material behaves fluid-like
- Energy dissipated as heat
- Flow-dominated behavior

Phase Angle and Loss Tangent

Phase Angle (δ):

- Lag between stress and strain
- $\delta = 0^\circ \rightarrow$ Purely elastic (all energy stored)
- $\delta = 90^\circ \rightarrow$ Purely viscous (all energy lost)

Loss Tangent:

$$\tan \delta = \frac{G''}{G'}$$

Interpretation:

- $\tan \delta \gg 1$: Very damped, fluid-like
- $\tan \delta \ll 1$: Elastic, solid-like
- $\tan \delta \sim 1$: Balanced viscoelastic behavior

Rheometry Techniques

1. Rotational (Shear) Rheometer

Common Configuration:

- Material sandwiched between plates
- Or cone-and-plate geometry
- Apply controlled strain or stress

Measurements:

Steady Shear:

- Measure viscosity: $\eta = (\text{shear stress})/(\text{strain rate})$
- Flow curves
- Shear-thinning or thickening behavior

Oscillatory Shear:

- Measure G' and G''
- Frequency sweeps
- Amplitude sweeps

Cone-Plate Geometry:

- Advantage: Uniform shear across radius
- Precise measurements
- Common in research

2. Creep Test

Procedure:

1. Apply constant stress
2. Watch strain vs time

Results by Material Type:

Elastic Solid:

- Immediate strain
- Then no further creep
- Constant strain (if truly Hookean)

Viscous Fluid:

- Strain increases linearly forever
- No asymptote

- Slope = $1/\eta$

Viscoelastic Material:

- **Kelvin-Voigt behavior:** Immediate elastic jump + slow creep → asymptote
- **Maxwell behavior:** Indefinite creep (has liquid component)

Information Gained:

- Directly measures compliance (how "soft")
- Time-dependent response
- Viscosity at long times

3. Stress Relaxation Test

Procedure:

1. Apply quick fixed strain
2. Hold constant
3. Measure stress decay over time

Results by Material Type:

Purely Elastic:

- Constant stress (no decay)

Viscoelastic:

- **Maxwell fluid:** Decays to zero eventually

$$\sigma(t) = \sigma_0 e^{-t/\tau}$$

- **With permanent network:** Decays to plateau

Information Gained:

- Relaxation time τ
- Material's internal timescale
- Separates elastic (short-term) and viscous (long-term)

4. Dynamic Mechanical Analysis (DMA)

Application: Solid samples (polymer bars, films)

Method:

- Oscillatory loading
- Often in tension or bending
- Similar concept to rotational rheometry

Advantages:

- For materials that can't flow into gap
- Temperature sweeps
- Glass transition measurements

5. Other Methods

Capillary Viscometers:

- For simple fluids
- Measure flow through tube
- Use Poiseuille's law
- Older method but still useful

Interpreting G' and G''

Practical Meanings

$G' \gg G''$ (Storage dominates):

- Material is **gel-like** or **solid-like**
- Can support deforming load elastically
- Barely flows
- Example: Firm gel, rubber

$G'' \gg G'$ (Loss dominates):

- Material is **liquid-like**
- Will flow and not hold shape
- Most energy dissipated
- Example: Viscous liquid, honey

$G' \approx G''$ (Crossover):

- **Critical point**
- Marks characteristic timescale
- Material transitions from solid to liquid behavior
- Important for gel point determination

Frequency Dependence

Many Soft Materials:

- $G' < G''$ at **low frequencies** (fluid-like, long times)
- $G' > G''$ at **high frequencies** (solid-like, short times)
- Crossover at $\omega \approx 1/\tau$ (relaxation time)

Physical Interpretation:

- High frequency (fast deformation): No time to relax → solid
- Low frequency (slow deformation): Plenty of time to relax → liquid

Example Plot:

- X-axis: Frequency (ω)
- Y-axis: G' , G'' (log scale)
- Show crossover point
- Identify relaxation time from crossover

Quantifying Softness

For Solids: Modulus

Young's Modulus or Shear Modulus:

Measure of Stiffness:

- High modulus → stiff → "hard"
- Low modulus → compliant → "soft"

Examples:

- Hard plastic: $E \sim 3 \text{ GPa}$
- Rubber: $E \sim 1 \text{ MPa}$ (1000× softer)
- Soft silicone gel: $E \sim 50 \text{ kPa}$ (60× softer than rubber)
- Brain tissue: $E \sim 1 \text{ kPa}$ (extremely soft)

Biological Relevance:

- Tissue engineering cares deeply about modulus
- Cells respond to substrate stiffness
- Preview of Engler et al. paper (Lectures 7-8)

For Fluids: Viscosity

Measure of Flow Resistance:

- Low viscosity → flows easily
- High viscosity → flows slowly

Examples (at room temperature):

- Water: $\eta \sim 1 \text{ mPa}\cdot\text{s}$ (very fluid)
- Blood: $\eta \sim 3\text{-}4 \text{ mPa}\cdot\text{s}$
- Olive oil: $\eta \sim 100 \text{ mPa}\cdot\text{s}$
- Honey: $\eta \sim 10,000 \text{ mPa}\cdot\text{s} = 10 \text{ Pa}\cdot\text{s}$
- Glycerol: $\eta \sim 1000 \text{ mPa}\cdot\text{s} = 1 \text{ Pa}\cdot\text{s}$

Non-Newtonian Behavior

Shear-Thinning:

- Viscosity **decreases** with shear rate
- Common in polymer solutions, paints
- Example: Ketchup (shaking lowers viscosity)

Shear-Thickening:

- Viscosity **increases** with shear rate
- Example: Cornstarch suspension (oobleck)
- Acts solid under impact
- Preview of Waitukaitis & Jaeger paper

Rheometer Detection:

- Flow curve: Stress vs shear rate
- Slope changes reveal non-Newtonian behavior

Frequency-Dependent Softness

Key Insight: Softness can depend on measurement frequency!

Example: Silly Putty

- Measured slowly (low ω): Low effective modulus (soft, flows)
- Measured quickly (high ω): High effective modulus (stiff, bounces)

Practical Implication: Must specify conditions when reporting "softness"

Examples and Case Studies

Laboratory Demonstration

Rheometer Reading:

- Show real data from rheometer

- Oscillatory test on known material
- Point out G' , G'' values
- Discuss crossover frequency

Tabletop Viscoelastic:

- Gelatin dessert
- Quick oscillation (tapping) vs slow deformation (letting sag)
- Relate to G' and G''

Jello vs Silly Putty

Jello at Room Temperature:

- Jiggles (G' low, near solid/liquid boundary)
- Breaks if strained too far
- Gel with low modulus
- $G' > G''$ but both relatively small

Silly Putty:

- Frequency-dependent as discussed previously
- Classic example of viscoelasticity

Polymer Dynamic Mechanical Analysis

Example: Polyvinyl chloride (PVC)

Below Glass Transition ($\sim 60^\circ\text{C}$):

- $G' \gg G''$ (glassy solid)
- Very stiff
- Brittle

Above Glass Transition:

- $G'' \gg G'$ (rubbery flow)
- Much softer
- Can flow

Demonstrates:

- Temperature plays similar role to frequency
- Time-temperature superposition

Data Example: Frequency Sweep

Generic Polymer Melt or Colloidal Paste:

Low ω :

- $G'' > G'$ (fluid-like)
- Material has time to flow

High ω :

- $G' > G''$ (solid-like)
- No time to relax

Crossover at ω_0 :

- Mark: $\omega_0 = 1/\tau$
- Identifies relaxation time

Shear-Thinning Example

Ketchup Viscosity:

- High viscosity at low shear (doesn't flow from bottle)
- Low viscosity at high shear (flows when shaken/squeezed)
- Flow curve shows decreasing viscosity with shear rate

Why: Structure breaks down under shear

Discussion Questions

1. Making Measurements

Scenario: New synthesized hydrogel

Question: Want to know if it's solid-like or liquid-like. What experiment?

Answer:

- Oscillatory shear test at relevant frequency
- Or simple poke test: rebounds (elastic) vs slowly indents (viscous)
- Look at G' vs G''

2. Interpreting Moduli

Data: Material has $G' = 1000$ Pa, $G'' = 200$ Pa at 1 Hz

Question: How would it behave if deformed rhythmically at 1 Hz?

Answer:

- Mostly elastic response
- Will return ~80% of energy
- Only 20% lost
- Will hold shape and only slowly relax

Follow-up: What if frequency increases where G'' rises and G' drops?

3. Measuring Viscosity Without High-End Rheometer

Question: How to measure honey viscosity?

Possible Answers:

- Timed flow experiment (drip and use gravity + Poiseuille's law)
- Falling ball viscometer (Stoke's law)
 - Drop marble in honey
 - Measure terminal speed
 - Compute viscosity

Engages: Creative thinking about measurements

4. Relaxation Time Thought Experiment

Comparison: Cold honey vs warm honey

Question: How would relaxation times differ?

Answer:

- Warm honey: Lower viscosity → faster relaxation (low τ)
- Cold honey: Higher viscosity → slower relaxation (high τ)
- At room temp: Flows quickly
- At fridge temp: Almost solid-like (τ very long)

Insight: "Colder = more solid-like" because molecular motion slows

5. Rheology in Everyday Life

Ketchup Question: Why does shaking bottle make it easier to pour?

Answer:

- Shear-thinning behavior
- Structure breaks down
- Viscosity decreases

- Easier flow

Milkshake Question: Why add polymers (like carboxymethyl cellulose) to make thicker?

Answer:

- Increase zero-shear viscosity
- Suspension stays uniform (slower creaming)
- Gives smoother "body"
- Better mouthfeel

Key Concepts Summary

Rheological Properties

Property	Symbol	Units	Meaning
Storage Modulus	G'	Pa	Elastic stiffness, energy stored
Loss Modulus	G''	Pa	Viscous dissipation, energy lost
Complex Modulus	G*	Pa	$\ G^*\ = \sqrt{G'^2 + G''^2}$
Loss Tangent	tan δ	-	G''/G' (damping ratio)
Viscosity	η	Pa·s	Flow resistance

Experimental Methods Summary

Method	Measures	Best For
Oscillatory Shear	G', G''	Viscoelastic characterization
Steady Shear	η(γ̇)	Flow curves, non-Newtonian
Creep	J(t)	Compliance, long-time behavior
Stress Relaxation	G(t)	Relaxation time, memory
DMA	E', E''	Solid samples, temperature sweeps

Practical Insights

Why Rheological Properties Matter

Material Processing:

- Polymer melt needs right viscosity to mold
- Cured rubber needs right modulus for application

Formulation Stability:

- Mayonnaise with higher G' holds shape on sandwich
- Paint with proper shear-thinning flows on brush but not off wall

Product Performance:

- Tire rubber needs damping (G'') for ride comfort
- But stiffness (G') for handling

Biological Systems:

- Mucus rheology affects clearance
- Blood viscosity affects circulation
- Cell mechanics affect function

Connecting Lab Numbers to Tactile Impressions

Why peanut butter doesn't flow from jar:

- High zero-shear viscosity
- Often has yield stress
- Requires finite stress to initiate flow

Why shampoo thins when squeezed:

- Shear-thinning behavior
- Polymer network breaks down temporarily

Preparation for Next Lecture

Next lectures: **Student Presentations** (Lectures 7-8, 2-hour session)

Prepare:

- Read selected paper carefully
- Understand key concepts and methods
- Prepare 10-12 minute presentation

- Be ready for questions from peers

Papers span:

- Historical foundations (Einstein, Onsager, de Gennes)
- Novel materials (auxetics, soft robots)
- Phase transitions (jamming, active matter)
- Applications (mechanobiology, shear thickening)

References

1. "Storage modulus (G') and loss modulus (G'') for beginners" - Rheology Lab
2. "Basics of Dynamic Mechanical Analysis (DMA)" - Anton Paar Wiki
3. Macosko, C.W. "Rheology: Principles, Measurements, and Applications" (1994)
4. Barnes, H.A. "A Handbook of Elementary Rheology" (2000)

Previous Lecture: [Lecture 5: Elastic vs Viscous vs Viscoelastic](#) **Next Lecture:** [Lectures 7-8: Student Presentations](#) **Course Home:** [Course Overview](#)

Metadata >

Author:: [Vatsal Sanjay](#)

Date published:: Jul 19, 2026

Date modified:: Jul 19, 2026

Back to main website

[Home](#), [Team](#), [Research](#), [Github](#)



[Edit this page on GitHub](#)